

ASSEMBLY QUICK GUIDE WORKTOPS

Wood is a living material. It expands and contracts to the changes in the environment, depending on variances in temperature and humidity. It's very important that once fitted, the timber can move naturally without restriction.



THE MOST IMPORTANT STEPS WHEN INSTALLING A WOODEN WORKTOP

1. Open the 'Service-box' supplied by Spekva.
2. Drill 10/15 mm round holes in the traverse on the cabinets and fix the worktop with the screws and washers supplied.
3. Screw/fit the worktop at the front, centre and back of the kitchen cabinets. Every 300 mm in depth and every 600 mm in length. Use the metal 'L-shaped' brackets for this in the middle of the cabinet. These have elongated sections, which allow for natural expansion.
4. Keep a 5mm space at the back when mounting the worktop to a wall.
5. Always glue tailored joints together, such as biscuit joints and side panelled solutions. Spekva supply the glue needed (labelled Smalfuge), and these tubes can be found within the service box. The glue applies white and then dries clear.
6. Use the self-adhesive aluminium foil by positioning it to the underside area of the worktop – over sources of heat and vapour such as dishwashers, stoves and radiators.
7. Treat with maintenance oil. It is vital that from the first day, worktops are saturated with the oil supplied and according to the instructions in our Maintenance Guide.

All mounting materials and oil can be found in the service box. For detailed explanations, please read our Assembly Instructions or watch our **Installation video**:



If in doubt; please don't hesitate to contact the SPEKVA customer centre:

+45 75 58 25 11

INSTALLATION EXAMPLES

